Creative Plaything/®

CHILDHOOD STARTS HERE

LEXI9WPP14 LEXINGTON PREMIUM PACK 14



The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.


Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63007-445 for important safety information.

Cartons for this Play Set:

- 1 63007-421 Lexington Gym 1 (Hardware)
- 1 63007-422 Lexington Gym 2 1 63007-423 Lexington Gym 3
- 1 63007-445 Lexington Roof (Hdwre & Instr)
- 1 SH946-102 Access Ladder, 5ft
- 1 AG942-400 Access Ladder Handles (Hdwre & Instr)
- 1 63058-202 4 Position Swing Beam
- 1 63060-222 9ft Swing Beam Legs (Hdwre & Instr)
- 1 50546-777 3 Swings, 1 Trapeze
- 15166-400 10 ft. Super Wave Slide
- 1 SM964-402 Gable Fans (Hdwre & Instr)
- 1 SM963-402 Dormer (Hdwre & Instr)
- 1 SH922-800Q Ramp (Hdwre & Instr)
- 1 SC909-800Q Lexington Play Walls (Hdwre & Instr)
- 1 SC910-800Q Lexington Play Floor (Hdwre & Instr)
- 1 SH304-101Q Pinnacle Rock Wall (Hdwre & Instr)
- 1 AG943-400 Slide Handle (Hdwre & Instr)
- 1 32404-102 Wall Slat

- Start by assembling the Lexington tower. Instructions and hardware are in the cartons noted at left. The gym is rotated 90° from the position shown in the instructions.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Lex step 13. Before installing the roof, find the post where the swing beam will mount. Drill 7/16" diameter holes through the post at 3", 7-1/4" and 15-1/2" below the top of the post as shown at right. The beam will be mounted to the front of the post using these holes. Insert one 5/16" weld nut into the top hole on the inside face of the post. Be sure the threads on the weld nut are clear, it will be captured by the roof support. Install the roof.
- · Lex step 21. The swing mount isn't needed.
- · Lex step 22. Do not install the safety rail.
- Mount the Swing Beam using instructions and hardware included in 63060-222. Mount the beam to the previously drilled holes at right rather than the way shown in the instructions. You may need to temporarily disconnect the roof from the post to put the beam in place.
- · Install the Gable Fans (SM964-402).





- Using a ladder, install the Dormer (SM963-402) in the position shown. Ladder access may be obstructed by later installations.
- Install the Play Floor (SC910-800Q).
- Install the Play Walls (SC909-800Q) along the back, front, and swing side of the gym.
- Install the Pinnacle Climber (SH304-101Q) on the end opposite the swings.
- Set the Ramp, Access Ladder and Slide as shown on the first page of this guide. Check spacing.
- Install the Ramp (SH922-800Q).
- Secure the access ladder using the method shown in step 20 of the Lexington instructions.
- Fasten the Access Ladder Handles (AG942-400) to the Access Ladder.
- Install the slide mount and slide using the method shown in steps 28 and 29 of the Lexington instructions.
- Install wall slats in the postions shown in images, using the methods from the Lexington Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- · Mount the hand grips to the entrance wall slats.
- · Mount the Slide Handle (AG943-400) above the slide.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.