



Dimensions of assembled package:
19' 7" wide x 16' 8" deep x 11' 6" tall

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63067-202 for important safety information.

Cartons for this Play Set:

1	63062-211	Ridgefield 1 (Hardware)
1	63067-202	Ridgefield 2 (Instructions)
1	63006-421	Williamsburg Box 1 (Hardware)
1	63006-422	Williamsburg Box 2
1	63006-423	Williamsburg Box 3
1	63006-445	Williamsburg Roof (Hardware)
4	40456-402	End Panel Assembly
2	40457-402	Side Window Panel
2	40458-402	Door Panel (Hdwre & Instr)
1	SM964-402	Gable Fans (Hdwre & Instr)
1	SM963-402	Dormer (Hdwre & Instr)
1	SH946-102	Access Ladder 5ft.
1	AG942-400	Access Ladder Handles (Hdwre & Instr)
1	15166-400	10 ft. Super Wave Slide
1	63058-202	4 Position Swing Beam
1	63076-303	9ft Beam Legs (Hdwre & Instr)
1	50546-777	3 Swings, 1 Trapeze
1	AH201-102Q	Rock Climbing Wall (Hdwre & Instr)
1	SC908-800Q	Wmsbg Play Floor (Hdwre & Instr)
1	63071-101	Ridgefield Play Walls (Hdwre & Instr)
1	63072-101	Ridgefield Play Floor (Hdwre & Instr)
1	AG943-400	Slide Handle (Hdwre & Instr)

- Start by assembling the Ridgefield tower. Instructions are in carton 63067-202. Other instructions and hardware are in the cartons noted at left. Do not use the Williamsburg instructions packed in the wood roof carton.
- Ridgefield step 2. Do not install the Sandbox Center on the front of the tower. Use the Floor Transition from the Ridgefield Play Floor (63072-101). See page 2 of the Ridgefield Play Floor instructions. Secure the Sandbox backs but wait to install the floors.
- Ridgefield step 12. Install only the angle braces under the porch. The other braces will interfere with the bottom clubhouse panels.
- Ridgefield step 18. The 9ft Beam will be mounted in the position pictured above; parallel to the roof.
- Ridgefield step 32. Do not install safety rail.
- Install the 9ft Swing Beam. Instructions are in 63076-303.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Complete installation of the Ridgefield porch play floor (63072-101) followed by the Wmsbg play floor (SC908-800Q).



- Install the lower clubhouse panels as shown in the instructions included with the door panel (40458-402).
- Install the Ridgefield porch Play Walls (63071-101).
- Install the Rock Climbing Wall (AH201-102Q) in the position shown.
- Set the access ladder and slide as shown in the picture on the preceding page. Check spacing.
- Fasten access brackets to the **inside** of the ladder rails. Secure the access ladder using the method shown in step 36 of the Ridgefield instructions.
- Fasten the Access Ladder Handles (AG942-400) to the Access Ladder.
- Install the slide mount and slide using the method shown in steps 38 and 39 of the Ridgefield instructions.
- Mount the Slide Handle (AG943-400) above the Super Wave Slide.
- Install the wall slats in the positions shown on the front page, using the methods from the Ridgefield instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.