Creative Plaything/®

LEXI9WPP10

LEXINGTON PREMIUM PACK 10



The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly. See the Instructions and Owner's Manual included in carton 63007-445 for important safety information.

& Instr)

Cartons for this Play Set:

1	63007-421	Lexington Gym 1 (Hardware)
1	63007-422	Lexington Gym 2
1	63007-423	Lexington Gym 3
1	63007-445	Lexington Wood Roof (Hdwre

SH946-102 Access Ladder, 5ft

AG942-400 Access Ladder Handles (Hdwre & Instr)

63058-202 4 Position Swing Beam

9ft Swing Beam Legs (Hdwre & Instr) 63060-222 3 Swings, 1 Trapeze 50546-777 15166-400 10 ft. Super Wave Slide AG943-400 Slide Handle (Hdwre & Instr) Gable Fans (Hdwre & Instr) SM964-402 Dormer (Hdwre & Instr) SM963-402

AA917-603 Fireman's Pole (Hdwre & Instr) AH201-102Q Rock Climbing Wall (Hdwre & Instr) SC910-800Q Lexington Play Floor (Hdwre & Instr)

40456-402 **End Panel Assembly Double Window Panel** 1 40459-402

40460-402 Door & Window Panel (Hdwre & Instr) Clubhouse Window Pack (Hdwre & Instr) 1 63073-101

63079-102 Monkey Bars (Hdwre & Instr)

- · Start by assembling the Lexington tower. Instructions and hardware are in the cartons noted at left.
- · Wait to install the access ladder, slide, and wall slats until after the rest of the play set is complete.
- · Lex step 7 & 8. Do not install the angle braces. The braces will not fit with the clubhouse panels.
- · Lex step 21. No Swing Mount is needed.
- · Lex step 22. Do not install the safety rail. It is not needed.

After completing the tower except access ladder, slide, and wall

- Using a ladder, install the Dormer (SM963-402) in the position shown. Ladder access may be obstructed by later installations.
- Install the Gable Fans (SM964-402).
- Install the 9ft Swing Beam. Instructions are in carton 63060-222.
- Install the Play Floor (SC910-800Q).
- Install the Clubhouse panels (40456-402, 40459-402, 40460-402) in the positions shown.
- · Install the Rock Climbing Wall (AH201-102Q) in the position shown.

LEXINGTON PREMIUM PACK 10



- Mount the Clubhouse window pack (63073-101) shutters and flower box to the door & window panel.
- Position the access ladder as shown. Secure the access ladder using the method shown in step 20 of the Lexington instructions. Fasten the brackets to inside the ladder rails.
- Fasten the Access Ladder Handles (AG942-400) to the Access Ladder.
- Install Monkey Bars (63079-102) on the front of the tower.
 Mount one side directly to the post.
- Install the slide mount and slide using the method shown in steps 28 and 29 of the Lexington instructions.
- Mount the Fireman's Pole (AA917-603) to the corner post as shown.
- Install wall slats in the positions shown on the front page, using the methods from the Lexington Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to an entrance wall slat to the right of the ladder. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.

- Mount the Slide Handle (AG943-400) above the Super Wave Slide.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.

Page 2