



Dimensions of assembled package:
21' 10" wide x 20' 4" deep x 12' 9" tall

The components of this gym can be combined with others to create different play sets.
This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.
See the Instructions and Owner's Manual included in carton 63007-445 for important
safety information.

Cartons for this Play Set:

1	63007-421	Lexington Gym Box 1 (Hardware)
1	63007-422	Lexington Gym Box 2
1	63007-423	Lexington Gym Box 3
1	63007-445	Lexington Roof (Hdwre & Instr.)
1	63008-221	Skybox 1 (Hdwre & Instr)
1	63008-222	Skybox 2
1	SC904-800Q	Skybox Play Floor (Hdwre & Instr.)
1	SC910-800Q	Lexington Play Floor (Hdwre & Instr.)
1	SJ926-810	Skybox Wood Roof (Hdwre & Instr.)
2	SM963-402	Dormer (Hdwre & Instr.)
1	63058-202	4 Position Swing Beam
1	63060-222	9ft Beam Legs & Brace (Hdwre & Instr.)
1	50546-777	3 Swings, 1 Trapeze
1	SD204-102Q	Lexington Picnic Table (Hdwre & Instr.)
1	AH201-102Q	Rock Climbing Wall (Hdwre & Instr.)
1	SH946-102	Access Ladder, 5ft
1	15166-400	10ft Super Wave Slide
1	63081-102	Ice Cream Stand (Hdwre & Instr.)
1	8400-202	Spiral Slide (Hardware)
1	63033-102	Spiral Slide Mount (Hdwre & Instr.)
1	AG943-400	Slide Handle (Hdwre & Instr.)
2	SM964-402	Gable Fans (Hdwre & Instr.)
1	AG942-400	Access Ladder Handles (Hdwre & Instr.)

- Start by assembling the Lexington tower. Instructions and hardware are in the cartons noted at left.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Lex step 2. Do not install the back Sandbox End. It will be replaced when installing the play floors.
- Lex step 19. Do not install the back End Wall Support. It will not be needed.
- Lex step 21. No Swing Mount is needed.
- Lex step 22. Do not install the safety rail. It will be used on the Picnic Table.
- Once the roof, roof supports, and ridge cap are installed, proceed with the Skybox tower.
- Skybox step 2. Omit the sandbox end under the gym. The floor transition from the Skybox Play Floor will be used instead.
- Skybox step 11. Use the front posts from The Skybox Roof (SJ926-810) in place of the post extensions.
- Skybox Step 17. On the side the Spiral Slide will mount, install only the wall slat closest to the main tower. The gap will be filled by the Spiral Slide.



- Ignore the special instructions regarding mounting with play floors in the Skybox instructions. A different method will be used.
- Install the Skybox Play Floor (SC904-800Q) and the Lexington Play Floor (SC910-800Q) using the method found in the Skybox Play Floor instructions on Page 3 titled "Install the Skybox Play Floor adjacent to a gym with a Play Floor." Some parts of the Lexington Play Floor will be cut to fit.
- Install the Skybox Wood Roof (SJ926-810)
- Using a ladder, install the Dormers (SM963-402) in the positions shown. Ladder access may be obstructed by later installations.
- Install the 9ft Swing Beam. Instructions are in carton 63060-222.
- Install the Picnic Table (SD204-102Q).
- Install the Rock Climbing Wall (AH-201Q) in the position shown; close to the front of the gym, away from the Spiral Slide exit.
- Set the access ladder and slide as shown in the picture on the preceding page. Check spacing.
- Fasten access brackets to the **inside** of the ladder rails. Secure the access ladder using the method shown in step 20 of the Lexington instructions.
- Install the slide mount and slide using the method shown in steps 28 and 29 of the Lexington instructions.
- Install the Ice Cream Stand (63081-102) at the end of the Skybox.
- Mount the Spiral Slide to the Skybox in the position shown above using instructions included in carton 63033-102. When you get to steps 12 & 13, see if the lower slide support bracket can be mounted to the Skybox post rather than the side safety rail. If it works, omit the side safety rail.
- Install wall slats in the positions shown on the front page, using the methods from the Lexington Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Mount the Slide Handle (AG943-400) above the Super Wave Slide.
- Install the Gable Fans (SM964-402).
- Fasten the Access Ladder Handles (AG942-400) to the Access Ladder.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.