

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63007-445 for important safety information.

Dimensions of assembled package:  
21' 11" wide x 14' 4" deep x  
11' 6" tall



- Start by assembling the Lexington tower. Instructions and hardware are in the cartons noted at left. **The gym is rotated 90° from the position shown in the instructions.**
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Lex step 21, no swing mount is needed
- Install the Gable Fans (SM964-402).
- Using a ladder, install the Dormer (SM963-402) in the position shown. Ladder access may be obstructed by later installations.
- Install the 9ft Swing Beam. Instructions are in carton 63060-222.
- Review the instructions for the Picnic Table, Picnic Adapter, and Play Floor. Install the adapter support and adapter upright from the Picnic Adapter (63096-102) leaving the gap on the front of the gym, closest to the swings.
- Install the Play Floor (SC910-800Q).
- Finish installing the Picnic Table (SD204-102) and Picnic Adapter (63093-102).
- Install the Rock Climbing Wall (AH201-102Q) at the end of the tower as shown above.
- Set the access ladder and slide as shown above. Check spacing.



### Cartons for this Play Set:

1	63007-421	Lexington Gym 1 (Hardware)
1	63007-422	Lexington Gym 2
1	63007-423	Lexington Gym 3
1	63007-445	Lexington Roof (Hdwre & Instr)
1	SH946-102	Access Ladder, 5ft
1	AG942-400	Access Ladder Handles (Hdwre & Instr)
1	63058-202	4 Position Swing Beam
1	63060-222	Swing Beam Legs 9ft (Hdwre & Instr)
1	50546-777	3 Swings, 1 Trapeze
1	15166-400	10 ft. Super Wave Slide
1	SM964-402	Gable Fans (Hdwre & Instr)
1	SM963-402	Dormer (Hdwre & Instr)
1	AA917-603	Fireman's Pole (Hdwre & Instr)
1	SD204-102Q	Lexington Picnic Table (Hdwre & Instr)
1	63093-102	Picnic Adapter (Hdwre & Instr)
1	SC910-800Q	Lexington Play Floor (Hdwre & Instr)
1	AH201-102Q	Rock Climbing Wall (Hdwre & Instr)

- Secure the access ladder using the method shown in step 20 of the Lexington instructions.
- Fasten the Access Ladder Handles (AG942-400) to the Access Ladder.
- Install the slide mount and slide using the method shown in steps 28 and 29 of the Lexington instructions.
- Install the Fireman's Pole (AA917-603) in the position shown.
- Install wall slats in the positions shown in images above using the methods from the Lexington Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment. Be sure to leave a gap for access to the sliding pole.
- Mount the hand grips to the entrance wall slats.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.