Creative Playthings

CHILDHOOD STARTS HERE

LEXI9WPP8 LEXINGTON PREMIUM PACK 8



The components of this gym can be combined with others to create different play sets.

This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly. See the Instructions and Owner's Manual included in carton 63007-445 for important safety information.

Cartons for this Play Set:

Cartons for this Play Set.		
1	63007-421	Lexington Gym 1 (Hardware)
1	63007-422	Lexington Gym 2
1	63007-423	Lexington Gym 3
1	63007-445	Lexington Roof (Hdwre & Instr)
1	SH946-102	Access Ladder
1	AG942-400	Access Ladder Handles (Hdwre & Instr)
1	63058-202	4 Position Swing Beam
1	63060-222	9ft Swing Beam Legs (Hdwre & Instr)
1	50546-777	3 Swings, 1 Trapeze
1	15166-400	10 ft. Super Wave Slide
1	AG943-400	Slide Handle (Hdwre & Instr)
1	AH201-102Q	Rock Climber (Hdwre & Instr)
1	SC909-800Q	Lexington Play Walls (Hdwre & Instr)
1	SC910-800Q	Lexington Play Floor (Hdwre & Instr)
1	63081-102	Ice Cream Stand (Hdwre & Instr)
1	SM964-402	Gable Fans (Hdwre & Instr)
1	SM963-402	Dormer (Hdwre & Instr)

Fireman's Pole (Hdwre & Instr)

- Start by assembling the Lexington tower. Instructions and hardware are in the cartons noted at left.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Lexington step 7. Do not install the angle brace mounted to the back platform end nearest the swings. It will interfere with the chalkboard.
- · Lexington step 21. No Swing Mount is needed.
- Lexington step 22. Do not install the safety rail. It will be used for the Play Walls.

After completing the tower except Access Ladder, Slide, and Wall Slats:

- Using a ladder, install the Dormer (SM963-402) in the position shown. Ladder access may be obstructed by later installations.
- · Install the Gable Fans (SM964-402).
- · Install the 9ft Swing Beam. Instructions are in carton 63060-222.

LEXINGTON PREMIUM PACK 8

AA917-603



- Install the Play Floor (SC910-800Q).
- Install the Play Walls (SC909-800Q) on front and swing side of the tower.
- Install the Ice Cream Stand (63081-102) on the back of the tower.
- Install the Rock Climbing Wall (AH201-102Q) in the postion shown.
- Place the access ladder and slide as shown in the picture on the preceding page. Check spacing.
- Fasten access brackets to the <u>inside</u> of the ladder rails.
 Secure the access ladder using the method shown in step 20 of the Lexington instructions.
- Fasten the Access Ladder Handles (AG942-400) to the Access Ladder.
- Install the slide mount and slide using the method shown in steps 28 and 29 of the Lexington instructions.

- Install wall slats in the postions shown on the front page, using the methods from the Lexington instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Mount the Slide Handle (AG943-400) above the Super Wave Slide.
- Install the sliding pole (AA917-603) in the position shown.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.