



Cartons for this Play Set:

1	63089-116	Norfolk II Box 1 (Hdwre & Instr)
1	63089-216	Norfolk II Box 2
1	63089-316	Norfolk II Box 3
1	63089-416	Norfolk II Roof
1	63089-606	Norfolk II Cargo Net
1	63045-505	Norfolk Tire Swing (Hardware)
1	63058-202	4 Position Swing Beam
1	63076-303	9 ft Beam Legs (Hdwre & Instr)
1	50546-777	3 Swings, 1 Trapeze
1	8364-400	10ft. Scoop Slide

Dimensions of assembled package:
11' 10" wide x 23' 8" deep x 11' 6" tall

The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63089-116 for important safety information.



- Assemble the Norfolk tower. Instructions and hardware are in the cartons noted above right.
- On step 29 be sure to install the swing mount on the side shown above.
- Install the swing beam. Instructions and hardware are in the 9 ft Swing Beam Leg carton (63076-303).
- Install the slide mount and slide using the method shown in steps 37 and 38 of the Norfolk instructions.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.