Creative Plaything/

WILL9WPP7

WILLIAMSBURG PREMIUM PACK 7

CHILDHOOD STARTS HERE



The components of this gym can be combined with others to create different play sets.

This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63006-445 for important safety information.



- Start by assembling the Williamsburg tower. Instructions and hardware are in the cartons noted above.
- Wait to install the Access Ladder, Slide, and Wall Slats until
 after the rest of the play set is complete.
- · Skip Wmsburg step 20 & 21.
- Install the swing beam. Instructions and hardware are in the 9' Swing Beam Leg Carton (63060-222).
- Install the Picnic Table (SD920-800Q).
- Install the Monkey Bars (63079-102). Mount one side directly to the corner post as shown above.
- Mount the Rock Climbing Wall (AH201-102Q) in the position shown.
- · Secure the Access Ladder (SH946-102) to the back of the

- instructions.
- Install the slide mount and slide using the method shown in steps 27 and 28 of the Williamsburg instructions
- Install the wall slats in the postions shown above, using the methods from the Williamsburg Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount the hand grips to the entrance wall slats.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.