Creative Playthings

CHILDHOOD STARTS HERE

WILL7WPPSS

WILLIAMSBURG PREMIUM PACK SPACE SAVER



The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63006-445 for important safety information.

- Start by assembling the Williamsburg tower. Instructions and hardware are in the cartons noted above right.
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the tower is complete.
- Wmsbg Step 14. Do not install the end wall support on the front of the tower where the space saver beam will mount. Install just the end wall support on the back of the tower.
- · Wmsbg Step 20. The swing mount is not needed.
- Skip step 21. Do not install the safety rail. It will be used on the picnic table.
- After the roof is in place install the Space Saver Beam (63087-101). Notice the hand grip below the gym brace shown above. Wait to secure that gym brace until after the handgrip is in place.
- Install the Picnic Table (SD920-800Q).
- Install the Rock Climbing Wall (AH201-102Q) on the opposite end from the beam as shown.

Cartons for this Play Set:

1 63006-421 Williamsburg Box 1 (Hardware)

1 63006-422 Williamsburg Box 2 1 63006-423 Williamsburg Box 3

1 63006-445 Williamsburg Roof (Hdwre & Instr)

1 SH946-102 Access Ladder, 5ft

1 63087-101 Space Saver Beam (Hdwre & Instr)
1 AH201-102Q Rock Climbing Wall (Hdwre & Instr)
1 SD920-800Q Wmsbrg Picnic Table (Hdwre & Instr)

8364-400 10ft. Scoop Slide



- Set the ladder and slide as shown above. Check spacing.
- Fasten access brackets to the <u>inside</u> of the ladder rails.
 Secure the access ladder using the method shown in step 18 of the Williamsburg instructions.
- Install the slide mount and slide using the method shown in steps 27 and 28 of the Williamsburg instructions
- Install the wall slats in the postions shown above, using the methods from the Williamsburg Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide. Mount the other hand grip to the adjacent post using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws. Use the unsecured gym brace to gauge the best position for the handle. Secure the gym brace.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.

WILLIAMSBURG PREMIUM PACK SPACE SAVER