



The components of this gym can be combined with others to create different play sets. This is the best order of assembly to create this specific set.

Read this sheet and all instructions included with the different parts before assembly.

See the Instructions and Owner's Manual included in carton 63006-445 for important safety information.

### Cartons for this Play Set:

1	63006-421	Williamsburg Box 1 (Hardware)
1	63006-422	Williamsburg Box 2
1	63006-423	Williamsburg Box 3
1	63006-445	Williamsburg Roof (Hdwre & Instr)
1	SH946-102	Access Ladder, 5ft
1	63058-202	4 Position Swing Beam
1	63060-222	9ft Swing Beam Legs (Hdwre & Instr)
1	50546-777	3 Swings, 1 Trapeze
1	15166-400	10 ft. Super Wave Slide
1	AG942-400	Access Ladder Handles (Hdwre & Instr)
1	AG943-400	Slide Handle (Hdwre & Instr)
1	SM964-402	Gable Fans (Hdwre & Instr)
2	SM963-402	Dormer (Hdwre & Instr)
1	AH201-102Q	Rock Climbing Wall (Hdwre & Instr)
1	SC907-800Q	Williamsburg Play Walls (Hdwre & Instr)
1	SC908-800Q	Williamsburg Play Floor (Hdwre & Instr)
1	63081-102	Ice Cream Stand (Hdwre & Instr)
1	63008-221	Skybox 1 (Hdwre & Instr)
1	63008-222	Skybox 2
1	SJ926-810	Skybox Wood Roof (Hdwre & Instr)
1	15140-400	14ft Swoosh Slide
1	50398-700	Swoosh Slide Skybox Pk (Hdwre & Instr)
1	SC904-800Q	Skybox Play Floor (Hdwre & Instr)
1	AP970-104	Bubble Panel (Hdwre & Instr)

- Start by assembling the Williamsburg tower. Instructions and hardware are in the cartons noted at left. Notice the **gym is rotated 90° from the position shown in the instructions**
- Wait to install the Access Ladder, Slide, and Wall Slats until after the rest of the play set is complete.
- Wmsbg step 2. Do not install the Sandbox End on the end adjacent to the Skybox. It will be replaced when installing the play floors.
- Wmsbg step 12. Do not install the End Wall Support adjacent to the Skybox. It will not be needed.
- Skip Wmsbg steps 20 & 21.
- Once the roof, roof supports, and ridge cap are installed, proceed with the Skybox tower.
- Skybox step 2. Omit the sandbox end under the gym. The floor transition from the Skybox Play Floor will be used instead.
- Skybox step 11. Use the front posts from The Skybox Roof (SJ926-810) in place of the post extensions.
- Skybox Step 17. Wait to install the wall slats on the back where the bubble panel will mount, and the side where the Swoosh Slide will mount until after installing the bubble and slide.



- Skybox Step 21 & 22. Install the slats in reverse orientation so the opening is on the opposite side. Install the ladder aligned with the opening.
- Ignore the special instructions regarding mounting with play floors in the Skybox instructions. A different method will be used.
- Install the 9ft Swing Beam. Instructions are in carton 63060-222.
- Install the Skybox Play Floor (SC904-800Q) and the Williamsburg Play Floor (SC908-800Q) using the method found in the Skybox Play Floor instructions on Page 3 titled "Install the Skybox Play Floor adjacent to a gym with a Play Floor." Some parts of the Williamsburg Play Floor will be cut to fit.
- Install the Skybox Wood Roof (SJ926-810).
- Install the Gable Fans (SM964-402).
- Install the Bubble Panel (AP970-104) and the wall slats on either side.
- Install the 14ft Swoosh Slide using the instructions in the Swoosh Slide pack (50398-700). Install the wall slats on either side.
- Using a ladder, install the Dormers (SM963-402) in the positions shown. Ladder access may be obstructed by later installations.
- Install the Play Walls (SC907-800Q).
- Install the Rock Climbing Wall (AH201-102Q) at the back of the main tower as shown above.
- Install the Ice Cream Stand (63081-102) at the end of the Skybox tower as shown above.
- Set the access ladder and slide as shown in the picture on the preceding page. Check spacing.
- Fasten access brackets to the **inside** of the ladder rails. Secure the access ladder using the method shown in step 18 of the Williamsburg instructions.
- Fasten the Access Ladder Handles (AG942-400) to the Access Ladder.
- Install the slide mount and slide using the method shown in steps 27 and 28 of the Williamsburg instructions.
- Install wall slats in the positions shown in images above and on page 1, using the methods from the Williamsburg Instructions. Gaps must be narrower than 3-1/2" or wider than 9" to prevent potential head entrapment.
- Mount one hand grip to the entrance wall slat between the ladder and the slide on the front of the gym. Mount the other hand grip to the adjacent post at the same height, using 1/4 x 1-1/2" lag screws and 1/4" flat washers. Drill 3/16" diameter pilot holes for the lag screws.
- Mount one Slide Handle (AG943-400) above the Super Wave Slide and one above the Swoosh Slide.
- Double-check all fasteners are secure and all recessed hardware is covered by hole caps.